

Installing a Zebra Card Printer Windows 2000 Printer Driver:

1. Select the Settings entry from the Start menu.
2. Select the Printers entry from the Settings menu.
3. Double-click the Add Printer icon.
4. Click the Next button.
5. Determine how your printer is connected; if it is a local or network printer.
6. Click the Next button.
7. Choose the Port you want to print from.
8. Click the Next button.
9. Click the Have Disk button.
10. Put the Driver Disk into the drive a:.
11. Change directories to Win2k.
12. Highlight the printer name and click the Open button.
13. Click the OK button.
14. Highlight the corresponding Zebra Card printer model.
15. Click the Next button.
16. Choose if you want the printer to be your default printer or not.
17. Click the Next button (do not change the printer name).
18. Choose if you want to share this printer or not.
19. Click the Next button.
20. Choose No (do not print a test page).
21. Click the Next button.
22. Make sure the printer is setup correctly.
23. Click the Finish button.
24. At the Digital Signature Not Found window, click yes to continue with the installation.

Installing a Zebra Card Printer Windows 95/98/Me Printer Driver

1. Select the Settings entry from the Start menu.
2. Select the Printers entry from the Settings menu.
3. Double-click the Add Printer icon.
4. Click the Next button.
5. Determine how your printer is connected.
6. Click the Next button.
7. Click the Have Disk button.
8. Put the Driver Disk into the drive a:.
9. Click the OK button.
10. Change directories to WIN95.
11. Highlight the corresponding Zebra Card printer model.
12. Click the Next button.
13. Highlight the corresponding printer port.
14. Click the Configure Port button to configure your port settings (refer to your printer manual for more details).
15. Click the Next button.
16. Click the Next button (do not change the printer name).
17. Choose No (do not print a test page).
18. Click the Finish button.

Installing a Zebra Card Printer USB Print Drivers and Port Monitor:

1. Connect the printer to the computer via the USB port (Windows will detect new hardware).
2. You will be prompted on the USB Directory to install the USB Driver.
3. Browse on CD drive for USB Driver files.
4. Install the Printer Driver.
5. Install the USB Driver.
6. Install the Port Monitor.
7. Reboot the Computer.
8. In the driver, go to the Printer Properties.
9. Check if it works: Go to Tools Enter the command V You should get a response via a Message Box.

Installing the ICM Color Profile

1. Copy the file to correct location:
If you have a **Windows 98** or **Me** operating system, copy the Color Utility to the C:/Windows/System/Color folder.
If you have a **Windows 2000** operating system, copy the Color Utility to the C:/Wnnt/System32/Spool/Drivers/Color folder.
2. Go to the **Start** button on the taskbar.
3. Highlight **Settings**.
4. And choose, **Printers**.
5. Right click on the **Zebra Card** printer icon and select **Properties**.
6. Click on the **Color Management** tab.
7. Click the "**Add...**" button, and select the **Color_matching1.icm** from the Color folder where you saved it.

Installing a Windows NT 4.0 Printer Driver:

1. Select the Settings entry from the Start menu.
2. Select the Printers entry from the Settings menu.
3. Double-click the Add Printer icon.
4. Click the Next button.
5. Determine how your printer is connected.
6. Click the Next button.
7. Click the Have Disk button.
8. Put the Driver Disk into the drive a:.
9. Change directories to NT40.
10. Click the OK button.
11. Highlight the corresponding Zebra Card printer model.
12. Click the Next button.
13. Highlight the corresponding printer port.
14. Click the Configure Port button to configure your port settings (refer to your printer manual for more details).
15. Click the Next button.
16. Click the Next button (do not change the printer name).
17. Choose No (do not print a test page).
18. Click the Finish button.